
VALUELINE - VLR-RC001 Code List

TV/TXT Codes

Accend	0711
ACE.....	0713
Admiral	0032,0155,1011
Adyson	0730
Agashi.....	0730
Aiko	0707,0711,0730
Aim	0711
Aiwa.....	0261
Akai	0005,0159,0169,0707,0711,0730,0731,0745,1020
Akiba	0711,0731,0742
Akito.....	0711
Akura	0711,0731,0738,0740
Alaron	0730
Alba	0705,0711,0730,0731,0738,0744
Albiral	0001
Allstar	0711
Amplivision	0739
Amstrad	0006,0711,0731,0740,1011
Anam	0711
Anam National	0711
Anitech	0711
Ansonic	0711
Aristona	0711
A.R Systems	0711
Arthur Martin	0739
ASA.....	0007,0009,0013,0032,0094,0155,0161,1010
Asberg	0711
Asuka	0731
Atlantic	0711,0730
Auchan.....	0739
Audiosonic	0160,0711,0731
Ausind	0008
Autovox	0004,0007,0012,0014,0015,0078,0079,0104,0153
AWA	
.. 0026,0027,0033,0159,0160,0189,0220,0706,0708,0709,0711,0714,	
.....	0730,0740,1006
Baird.....	0162,0737
Basic Line	0163,0711
Baur.....	0711,1017,1037
BEKO	0170,0226,0711,0719,1018,1024
BEST	0741
Blaupunkt	
... 0010,0017,0018,0020,0054,0231,0232,0233,0234,0236,0241,1004	
Blue Sky	0711,0719,0738,0742,0744
BPL	0026,0160,0162,0163,0711
Brandt	0733,0735,0746
Brinkmann	0711
Brionvega	0104,0155,0164,0165,0200,0201,0257,0711,1011
Britannia	0730
Bruns	0158
BSR	0016,0019,0021
Bush(UK)	0022,0711,0738

Cabletime	0246,0247,0251
Carad	0717
Carena	0742
Century	0145,0146,0155
CGE	0019,0023,0024,0145,0151,0169,0170,0231,1004
CGM	0093
Chaparral	0216
Clarivox	0001,0166,0167
Clatronic	0705,0711
CODIAM	0138
Condor	0711,0730
Contec	0033,0016,0730
Continental Edison	0733,0744
Crosley	0024,0025,0145,0155,0231,1004
Crown	0705,0711,0741,0744,1008
CS Electronics	0730
CTC Clatronic	0096
Daewoo	0168,0209,0711,0730
Dainichi	0730
Dansai	0707,0711,0730
Dansette	0740
DSE (Digitor)	0026,0027,0033
Decca(UK)	0002,0004,0026,0028,0031,0258,0711
Dual	0255,0258,0711,0737,1011,1017
Dual-Tec	0004,0011,0019,0029
Dumont	0155,1010,1023
Elbe	0001,0171,0711,0717
Elbe-Elbit	1011
Elektronika	1008
Elin	0730,0745
Elite	0108,0711,1004
Elman.....	0019,0029,1023
Elta	0730
Emerson	0146,0155,0711,1010
Euroman	0711,0730,0741,1008
Europa	0711
Europhon.....	0000,0004,0019,0029,0030,0146,0711,1023
Expert	0739
Fenner	0033,0193,0240
Ferguson	0733,0735,0746
Fidelity(UK)	0003,0034,0229,0711,0730
Filmnet	0202,0248
Finlandia	0745,1010
Finlux	0007,0008,0009,0013,0025,0026,0029,0035,0094,0161,0169,0221,0711,1010,1023
Firstline	0711,0730,0738
Fisher.....	0025,0036,0155,0167,0170,0255,1017
Flint	0742
Formenti-Phoenix .	0003,0008,0025,0037,0038,0159,0730,1004,1023
France Telecom	0266
Friac	0741
Funai	0016,0160,1019
Galaxis	0711
GBC	0002,0004,0019,0025,0026,0031,0033,0039,0040,0041,0042
Geant Casino	0739
GEC(UK)	0711
Geloso	0004,0019,0025,0032,0033,0039,0149,0150

General	0733,0743
Genexxa	0740
Goldhand	0730
Goldstar	0003,0004,0043,0080,0153,0172,0252, 0700,0701,0711,0730,1011
Goodmans	0119,0707,0711,0737,0744
Gorenje	0170,0173,0741,1008
Granada(UK)	0002,0004,0027,0041,0044,0045,0046,0047, 0048,0049,0711,0735,0739,1010
Grandin	0705,0711,0717,0719,0739,0742
Great Wall	0253
Grey	1025
Grundig	0003,0010,0018,0020,0045,0050,0051,0053, 0054,0056,0094,0711,0744,1038
Halifax	0730
Hampton	0730
Hanseatic	0025,0027,0037,0044,0052,0055,0258,0711
Hantarex	0000,0711
Harwood	0740
Hauppaugel	0026,0711
HCM	0740
Hemmermann	0057
Hinari	0033,0044,0058,0059,0060,0711,0744
Hisawa	0739,0742
Hisense	1040
Hitachi	0004,0040,0041,0042,0044,0047,0055, 0061,0062,0063,0064,0065,0066,0067,0068, 0174,0221,0222,0710,0711,0737,1045,1046
Hitsu	0742
Hoshai	0742
Hotel TV	0704
Huanyu	0730
Hygashi	0730
Hyper	0003,0004,0033,0153,0193,0730
Hypson	0739,0742
ICE	0730
Ices	0730
Imperial	0019,0023,0024,0145,0151,0169,0170,0231,0711,1004
Ingelen	0717,0744
Inno Hit	0000,0004,0031,0043,0060,0146,0175,0711,1004
INTER (265)	0725
Intercord	1017
Interfunk	0005,0027,0040,0045,0046,0052,0069, 0070,0071,0073,0075,0155,0711
Intervision	0711,0742,0744,1023
Irradio	0008,0039,0043,0060,0153,0262,0711
Iskra	1023
IT	0723
ITS	0730
ITT-Nokia	0005,0032,0033,0040,0041,0045,0049,0069, 0070,0071,0072,0074,0076,0162,0168,0176,0177,0717,0745
Janco	0249,0250
JEC	0707
JVC	0077,0119,0178,0179
Kaisui	0163,0711,0730,0742
Kamp	0730
Karcher	0159,0163,0175,0711,0717,0741,1008

Kawasho	0730
Kendo	0146,0711,0717,1011
Kennedy	0025,0078,0079,1011
Kingsley	0730
Kneissel	0711,0717
KONIG	0027
Konka	0711,1041
Kontakt	0744
Korting	0037,0155,0157,0741
Kotron	0740
Kuba	1017
Kyoshu	0740
Lenco	0033,0039,0183,0238,0239,0240,0711,1023
Lecson	0711,0718
Lenoir	0004
Leyco	0705,0711
LG	0711,0730,1039
Lifetec	0711,0738
Linton	1017
Loewe Opta	0052,0081,0155,0156,0189,0213,0242,1022
Logik	0028
Logix	0738
Luma	0032,0082,0711,1011
Lumatron	1011
Luxor	0005,0045,0047,0055,0068,0083,0084,0085, 0086,0087,0162,0177,0745,1010
Magnadyne	0000,0019,0025,0029,0057,0147,0149,0150,0155,1023
Magnafon	0000,0003,0008,0029,0030,0730,1023
Manesth	0707
Manhattan	0738
Marantz	0026,0027,1017
Mark	0730
Matsui	0004,0006,0028,0041,0088,0182,0705,0707,0735,0742,0744
Maximal	0058
Maxwell	1023
Medion	0738
Megas	0717
Melectronic	0255,0711,0730,0737,1010,1017
Melvox	0739
Metz	0018,0053,0089,0090,0091,0155,0180,0183
Micromaxx	0738
Minerva	0010,0018,0045,0051,0053,0744
Minoka	0740
Mitsubishi	0044,0052,0092,0119,0154,0155,0181,0182,0711
Mivar	0000,0003,0093,0094,0095,0245,0259,0730,0734
Morgans	0711
MTC	0730
Multisystem	0159
Multitec	0738
Multitech	0096,0170,0172,0711,0730
Murphy(UK)	0041,0730
NEC	0184,0711,0742
Neckermann	0004,0026,0044,0055,0082,0097, 0170,0711,1008,1011,1017,1037
N.E.I.	0166,0711
Neufunk	0711,0717
New Tech	0737

Nicamagic	0730
Nikkai	0707,0730
Nobliko	0003,0008,0029,0051,0146,0730,1023
NOKIA	0720,0745,1004,1010
Nordmende	0065,0067,0075,0098,0099,0100,0101,0102, 0103,0104,0134,0185,0186,0222,0711,0733,0737,1003,1036
Oceanic(F)	0005,0040,0105,0106,0107,0739
Okano	0711
Onceas	0004
Orion	0006,0016,0028,0057,0088,0108,0109, 0187,0188,0189,0711,0735,0740,1001
Ormond	0738
Osaki	0711,0740
Otto Versand	0025,0027,0044,0052,0055,0711,1017
Pael	0003,0008,0730
Palladium	0197,0711
Palsonic	0711,0740
Panama	0730
Panasonic/National	0001,0003,0019,0037,0040,0106,0110,0111, 0112,0114,0190,0212 ,0241,0711,0745,1036,1052
Pathe Cinema	0730,0739
Pershin	0739
Philco ...	0019,0023,0024,0025,0151,0155,0169,0170,0231,0711,1004
Philex	0229
Philips	0003,0026,0027,0046,0073,0113,0115,0155, 0191,0192,0193,0194,0223,0266,0230,0242,0265, 0711,0737,1009,1011,1017,1024,1033,1034,1050,1051
Phoenix	0730
Phonola	0175,0711,0730
Pilot (1624Y)	0729 (PIP)
Pilot (P1707Y)	0721
Pilot (P3033)	0727
Pilot (P4005)	0726
Pilot (P567)	0728
Pilot (P716)	0724
Pioneer	0000,0027,0067,0243,0711,0737
Polestar	0214
Powerpoint	0744
Prandoni-Prince	0008,0032,0146,1023
Praxis	0217
Profitronic	1023
Proline	0746
Prosat	0001
Prosonic	0705,0711,0730,0738
Protech	0738
Provision	0711
PYE	0711
Uuadra Vision	0739
Quasar	1023
Quelle	0004,0005,0007,0008,0009,0010,0013,0016,0026, 0027,0028,0045,0050,0051,0052,0069,0094,0153,0221, 0231,0232,0234,0235,0236,0711,0738,1003,1004,1007, 1008,1010,1011,1022,1035,1036
Radiola	0242,0711
Radiomarelli	1023
Radiotone	0705,0740
Rank(UK)	0022

RBM(UK)	0022,0094
RCA	0204,0210,0211,0746
Rediffusion(UK)	0005,0041,0116,0745
Red Star	0711
REX	0011,0021,0032,0078,0079,0118
RFT	1023
Rhapsody	0730
Roadstar	0039
Royal Lux	0740,0741
SABA	0000,0065,0067,0075,0085,0098,0099,0100,0103, ... 0117,0155,0185,0186,0222,0224,0733,0735,0737,0745,0746,1032
Sagem	0717,0742
Saisho	0004,0006,0028,0088,0182,0244
Salora	0005,0047,0048,0055,0066,0068,0069,0076,0082, ... 0086,0097,0162,0177,0195,0249,0250,0267,0268,0745,1010
Sambers	0000,0004,0008,0029,0030,0043,1023
Samsung	0026,0033,0043,0159,0160,0170,0175,0212,0215,0264, ... 0702,0703,0711,0716,0730,1000,1015,1016,1029,1031,1048
Sandra	0730
Sansui	0711
Sanyo	0013,0031,0044,0074,0119,0120,0121,0122,0123,0162, ... 0167,0170,0182,0195,0205,0711,0730,1043
Schneider	0004,0011,0015,0019,0025,0026,0036,0038,0255,0258, ... 0262,0711,0737,0738,1011,1017,1023,1028,1030
SEG	0096,0711,0730,0738,0744
SEI- Sinudyne	1001,1011,1023
Seleco	0011,0058,0078,1011
Sentra	0707
Serino	0717,0742
Sharp	0044,0054,0119,0124,0196,0198,0225,0227,1047
SHOV	0033
Siarem	0000,0025,0029,0155,1023
Sicatel	0001
Siemens	0010,0231,0232,0233,0234,0236,0711,1004
Siesta	0254
Silva	0730
Silver	0160,0711
Singer	0025,0029,0147,0149,0155,0711,0739,1023
Sinudyne	0006,0016,0025,0026,0029,0057,0109, ... 0125,0155,0192,0197,0711
Skysonic	0718
Skyworth	1044
Solavox	0745
Sonolor	0739
Sony	0028,0119,0126,0127,0128,0129,0130,0182,0199,0228,0260,1049
Stern	0078
Sunkai	0742,0744,1001
Sunstar	0705
Superla	0730
Supertech	0730
Susuma	0735
Sydney	0730
Sytong	0730
Tai Wah.	0218,0219
Tandberg	0016,0180,0266,1011
Tashiko	0730

Tatung	0002,0004,0026,0028,0031,0131
TCL	1042
Teac	0712,0740,0742
TEC	0735,0743,1011
Tech Line	0738
Technics	1036
Technovision	0263
Tele +1	0248
Teleavia	0186,0733
Telefunken ...	0067,0075,0098,0132,0133,0134,0135,0140,0185,0186, 0231,0235,0733,0735,0737,0743,0746,1003,1004,1026,1032
Teleservice	0203,0246
Teletech	0738
Televideon	0730
Televiso	0739
Tensai	0013,0016,0033,0037,0039,0178,1023
Tevion	0738
Thomson ...	0065,0067,0075,0078,0098,0100,0103,0185,0186,0222, 0722,0733,0735,0737,0743,0746,1027,1032
Thorn-Ferguson ...	0001,0135,0136,0137,0140,0144,0148,0152,0160, 0186,0229,0256,0735,1010,1011
Tokyo	0707,0730
Toshiba	0022,0044,0094,0119,0138,0139,0141, 0142,0707,0732,1035,1037
Transonic.....	0742
Transtec	0730
Trilux	1005,1021
Triumph	0732
Uher	0011,0012,0036,0037,0038,0078,0255,1017
Ultravox	0003,0025,0082,0096,0146,0155,0730
Unimor	1002,1012
Universum	0094,0160,0221,0738,0741
Univox	0001
Vegavox	0169
Videocon	0033,0138,0141,0715
Videologique	0730
Videotechnic	0730
Visiola	0730
Voxson	0032,0155
Waltham.....	0733
Watson	0037,0705,0738,1004
Watt Radio.....	0001,0003,0025,0029,0030,0057,0730,1023
Wega Color	0119,0143
Wharfedale	0718
White Westinghouse	0003,0037,0159,0730
Winco	0740
Yamishi	0742
Yoko	0004,0159,0730,0741,1008
Zanussi	0078
Zenith	0203,0237
Others	0206,0207,0208,1013,1014

VCR Codes

Aiwa	0356
Akai	0269,0270,0271,0281,0309,0310 ,0357
Alba	0356
Anitsch	0311
ASA	0282
Baird	0271,0273
Blaupunkt	0272,0274,0275,0312,0369
Blue Sky	0356
Brinkmann	0356
Brionvega	0276,0283
Bush(UK)	0281,0356
CGE	0270,0277
CGM	0291
Decca(UK).....	0278,0356
Dual	0273,0279
Elbe	0313
Emerson	0286
Finlux	0278
Firstline	0356
Fisher	0280,0314,0315,0316
Funai	0359
GBC.....	0281
GEC(UK)	0278
Geloso	0281
General	0358
General Technic	0356
Goldstar	0282
Goodmans	0301,0356
Granada(UK)	0272,0278,0283,0314,0369
Grundig	0272,0275,0284,0356,0361,0369,0755
Hanseatic	0278,0285
Hinari	0281,0286,0287,0317,0360
Hitachi	0273,0281,0285,0288
Imperial	0277,0289
Interfunk	0278,0290
Intervision	0356
ITT-Nokia	0270,0273,0276,0290,0291,0292,0316
JVC	0270,0273,0292,0318,0319,0320,0321,0328
Kendo	0356
Kneissel	0356
Lenco	0325,0355
Lifetec	0356
Loewe Opta	0272,0278,0369
Logik	0287,0322,0360
Luma	0322
Luxor	0285,0291
Magnasonic	0291
Marantz	0272,0278,0301
Matsui	0287,0322,0332,0356
Medion	0356
Memorex	0282,0314
Metz.....	0272,0275,0294,0369,0370
Micromay	0356
Minerva	0272,0275,0369
Mitsubishi	0278,0281,0293,0320,0362,0751
Multitech	0281,0325
NAD	0363

NEC	0273,0313,0320
Neckermann	0270,0272,0273,0278,0285,0286,0369
Nobliko	0272,0369
Nordmende	0270,0273,0279,0292,0295,0296,0297,0318,0319, 0321,0323,0324,0326,0327,0328,0329,0330
Okano	0356
Orion	0286,0322,0331,0332,0333,0356,0360
Osaki	0282
Otto Versand	0278,0285
Palladium	0271,0281
Panasonic /National	0274,0290,0312,0354
Penney	0313
Pentax	0288
Philips	0278,0302,0334,0335,0336,0369
Phonola	0278,0335
Pilot (1621Y)	0753 (Video2)
Pilot (P1528Y)	0752
Pilot (P3050)	0754
Pioneer	0278,0320,0334,0336,0363,0364,0365
PYE	0320
Quartz	0314
Quelle	0272,0275,0278,0286,0298,0369
RCA	0349
REX	0273,0292,0319
SABA	0270,0273,0279,0292,0295,0318,0319,0321,0326,0337,0338
Saisho	0286,0287,0322,0332,0356,0360
Salora	0283,0285,0314
Samsung	0289,0756
Sansui	0320,0356
Sanyo	0291,0314,0316,0339
Schneider	0278,0281,0289
Sears	0315
SEG	0281,0289
Seleco	0309
Senta	0277
Sharp	0301,0302,0341
Shinton	0281
Siemens	0272,0275,0291,0369
Sinudyne	0278,0287
Sony	0298,0299,0340,0342,0343,0344,0367,0750,0757
Tandberg	0322
Tatung	0278,0356
Technisat	0356
Telefunken	0270,0273,0279,0292,0318,0319,0321,0323,0330,0345,0346,0347
Telemeister	0359
Tevion	0356
Thomson	0270,0273,0279,0292,0318,0323,0324,0328
Thorn-Ferguson	0270,0273,0300,0303,0304,0305,0306,0308, 0319,0329,0330,0348,0368
TMK	0286
Topline	0356
Toshiba	0273,0292,0307
Uher	0273,0289
Ultravox	0276
Universum	0356
Vector	0313

Victor	0318,0328,0366
Video	0313
White Westinghouse	0276,0282
Xenon	0322
Others	0350,0351,0352,0353

SAT/DSS Codes

AB	0812
Aegir	0514
Akai	0499
Alba	0407,0522
Aldes	0511,0514
Alfa Gold	0810,0811
Allsat	0499,0512
Allsonic	0511
AlphaStar	0499,0826
Amstar	0847
Amstrad	0371,0372,0408,0488,0497,0515,2014
Ankaro	0373,0511
Anttron	0522
Apollo	0402
Arion	0510,2003
Armstrong	0499
Asat	0499
Aston	0498
Astra	0372,0409,0488,0520
Astro	0502,0514,0522
ASTRX	0840,0842,0843,0846
Audioton	0512,0522
Aura	0430,0487
Barcom	0373
Benjamin	0468
BEST	0453
Bigsat	2013
Boca	0497
BSkyB	0880
Bush(UK)	0402
Cambridge	0375
CANAL+	0804
Chaparral	0216,0374,0410
Citycom	0507
CNT	0514
Commlink	0511
Comtec	0511
Condor	0520
Conrad	0520
Cosat	0512
Datcom	2005
Digital	2006
Distrisat	0499
DMT	2013
DNT	0409,0428,0430,0487,0499
Drake	0376,0445,0446,0447,0495
DSR	2003

Dynasat	0491,0492
Echostar	0377,0378,0379,0386,0409,0411,0412,0457,0458, 0461,0462,0486,0800,0827,0855,0862,2008
EH.Galaxy	0858
Einhell	0497,0511
EISAT	0822
Electrosat	0870
Elekta	0514
Elta	0499,0512
EMME ESSE	0463,0464,0465
Europa	0499
Eurosky	0421,0497,0520
Euro Space	0850
Eurostar	0465,0513,0520,0872
Exator	0522
Fagor	0512
Ferguson	2003
Finlux	0414,0415
Force	0836
FortecStar	0458,0808,0809,0846,0850,0851,0852,0853, 0854,0856,0857,0859,0866,0867,0876,0878,0879
Fracarro	0380,0381
Freecom	0426
FTE	0399
Fuba	0413
Funtach	0823,0824
Galaxis	0511,0512
Galaxys	0873
Giucar Record	0382,0416
GMI	0521,2019,2020,2021,2022,2023,2024
Grandin	0496
Grey	2003
Grundig	0383,0400,0402,0484,2025
Hanseatic	0516
Hanuri	0514
Heliocom	0520
Hevet	2007
Hirschmann	0415
Hitachi	0483,0828,0829,2026,2027
HTS	0827
Hughes	0828,0829
Humax	0505,2004,2012
Huth	0421,0479,0511,0512,0520
HWALIN	0816
ICX International	0417
ID Digital	2004
Info	2010
Interstar	2011
Intervision	0512,0520,0523
ITT-Nokia	0384,0385,0418
Jeemon	0386
Jerrold	0454
Johansson	0387,0512
JSR	0386
Kathrein	0388,0389,0390,0419,0469,0499,0507,0522
Konka	2028
KR	0522

Kyostar	0522
Lasat	0497,0514,0520
Lemon	0503
Lenco	0423,0426,0480,0481,0482
Lexus	0499
Life Sat	0504,0516
LG	2029
Lorenzen	0497,0520
Luxor	0384,0391,0392
Macab	0420
Macom	0444
Magnavox	0477,0830,0831
Manhattan	0512,0514
Marantz	0499
Maspro	0388,0393,0402,0490
Max	0520
M & B	0516
Mega.....	0499
Metronic	0496,0507,0511,0514,0522
Metz	0383
Microsat	0874
MINA	0494
Minerva	0383,0400,0484
Mitsubishi	0489
MME	0217
Morgans	0421,0497,0499,0512,2012
Motorola	2000
NEC	0422,0478,0493
Neckermann	0421
Neosat	0845
Neotion Box	2007
Network	0394
Neuhaus	0520
Neusat	2013
New Star	2015
NOKIA.....	0502,0720,0807
Nordmende	0514
Obritech	0426
Octagon	0522
Openfox	2013
Opentel	2016
Optex	0512
Opticum	2006,2016
Pace	0394,0395,0400,0402,0485,0500,0814,0815,2001
Palcom	0396
Palladium	0421
Palsat	0423
Panasat	0819,0863
Panasonic /National	0473,0832
Panda	0520
Pansat	0455
Philips	0402,0424,0425,0460,0477,0499,0507,0518,0522,0803,0830,0831,0841
Phonotrend	0511,0512
Pioneer	0474
Polsat	2009,2017
Preisner	0497

Premier	0802
Premium X	0501
Primestat	0454
Prosat	0405,0451,0479,0511,0523
Protek	0504
Provision	0514
PSR	0858
PTT_TELCOM	0515
Quadral	0511,0523
Quelle	0383,0520
Radiola	0499
Radix	0409,0428,0430,0487
Rainbow	0522
RCA	0450,0818,0835
RC-AK	0456
RFT	0499,0511
RM(RM2200)	0860
Rover	0523
RTG.(SpaceNet)	0846
SABA	0514,0520
Sagem	0518
Sakura	0397,0398
Salora	0391,0418
Samsung	0459,0475,0476,0801,0877,2030
SAT 100	0372,0488
Sateco	0426
Satcom	0515,0516,0520
Satline	0523
Satpartner	0514,0522
Schacke	0522
Schwaiger	0516
Scientific Atlanta	0452
SEG	0516
Seleco	0512
SET	0825,0837,0838,0839
Siemens	0383
Sigma	2007
Signal	0456,0850,0855
Sintrack	0427
Skardin	0821,2002
Sky Box	2007
Sky Digital	0880,0881
Skymaster	0479,0511,0513,0516,0517,0523,0825,0882,0883
Skymax	0499
Skyvision	0512
SL	0497
Sony	0472,0834
Star	0459,0470,0802,0846,0868,0871,0875
Strong ..	0399,0423,0426,0480,0492,0508,0514,0522,0864,0865,0868
STS	0393
STV	0413
Sun Moon Star	0813
Sunstar	0497
Super Max	0846,0848,0849,0850
Supex	0858,0862,0869
Tadiran	0817
Tagra	0512

Tantec	0396
Technisat	0409,0428,0429,0430,0431,0487,0499,2018
Technosat	0263,0467,0802,0869
Technowelt	0520
Tedexlex	0466
Teknika	0471
Telasat	0516
Teleciel	0522
Telecom	0884
Teleka	0522
Telemaster	0514
Telemax	0432
Telemeister	0398,0409,0428,0430,0469,0487
Teletech	0513
Telewire	0512
Thomson	0520,2009,2017
Thorn-Ferguson	0394,0395,0400,0401,0402,0433,0485
Tokai	0499
Tonna	0512
Topfield	0509
Toshiba	0442,0444,0506,0833
TPS	0805
Triumph	0506
Trwam	2005
Unbranded	0481
Uniden	0403,0404,0406,0443,0830,0831
Unisat	0499
United Satellite	0440
Universum	0520
US Electronics	0417
Vector	0430,0487
Ventana	0499
Viewstar	0477
Vision	0519
Vortec	0459,0801,0855
Vortic Star	0801
Vtech	0434,0507
Wela	0497
Wetekom	0516
Winer	0080,0387,0449,0844
Wintegarten	0511
WISI	0409,0420,0435,0436,0437,0438,0439
Woorisat	0514
XSAT	0500
Zehnder	0390,0507,0514
Zenith	0441,0444,0445,0446,0447
Zinwell	0821
Zodiac	0522
Others	0820,0861

CABLE Codes

ABC	0452
Jerrold	0417
Paragon	0806

TADA 0448

HIFI Codes

Blaupunkt 0568
Fisher 0529
Hitachi 0530
Kenwood0527,0531,0532,0533,0534
Lenco0595,0596,0597,0598,0599,0600,0601
Nordmende 0535,0549
Onkyo 0536,0537
Panasonic /National 0538
Pioneer 0545
Sanyo..... 0539
Sharp 0531
Sherwood0540,0541,0577,0578
Skardin 0644
Sony 0617
Technics 0542
Yamaha 0543,0544

CD Codes

Aiwa 0581
ATLE 0579
Denon 0547
Fisher 0546
Haitai 0548
Inkei 0541
JBL 0623,0624
JVC 0605
Karcher 0549
Kenwood 0550,0580
Lenco
... 0060,0549,0585,0586,0587,0588,0589,0590,0591,0592,0593,0594
Magnavox 0553,0576,0604
Mission 0553
NEC 0551
Onkyo0613,0614,0615,0616
Philips0552,0553,0579,0604
Pioneer 0554,0555,0610
Proton 0553
Radiotone 0549
ROTEL 0553,0582,0583
SAE 0553
Sansui 0603
Sanyo 0604,0606
Sharp 0550,0566
Sony0556,0557,0575,0607
Sylvania 0553,0604
Teac 0608,0611
Technics 0558,0609
Victor 0605
Yamaha 0612

LD/DVD Codes

Afreedy	0688
Aiwa	0626,0649
Alba	0680
AMC	0643
APEX	0672
Arianet	0654
ATLM	0627,0671
BBK	3003,3004,3005,3006,3007,3008,3009
Bentley	0635
BSkyB	0680
Bush(UK)	0680,0685,0689
Caravell	0622
CineULTRA	0689
CONIC	0673
Daewoo	0660,3013
Denca	0665
Denver	0689
Denzel	0684
Desay	0625
Diamond	0683
Dual	0684
Eltax	0642
Elyxio	3000
Encore	0688
Enzer	0684
Ferguson	0679
Goldstar	0633,0682
Grundig	0655,0686
Harman/Kardon	0690
Hitachi	0684
JMB	0686
JVC	0636,0664,3012
Kenwood	0572,0630,0663
Kiss	0684,3015
Lenco	0689
Lecson	0687
LG	0682
Logik	0669
Magnavox	0571
Manta	3011
Matsui	0683,0686
Maxview	0670
M & B	0670
Microsoft	0619,0620
Mitsubishi	0662
Monyka	0684
Multek	0638
Neufunk	0684
Onkyo	0647,0653
Orion	0686,3010
Oritron	0683
Pacific	0676,0677,0678,0679

Panasonic /National	0573,0574,0629,0639
Philips	0559,0675
Phonotrend	0689
Pioneer	0571,0658
Raite	0684
RCA	0602,0661,0667
REC	0685
Red Star	0650,0652
Roadstar	0685,0689
Sampo	0688
Samsung	0637,0648,0666
Sansui	0686
Sanyo	0681
Schneider	0679
Schwaiger	0679
SEG	0684
Sharp	0628,3010
Skymaster	0656
Sokol	0645
Sony	0575,0631,0632,0641,0657
Tatung	0659
Teac	0634
Telestar	0651
Tevion	0683
Thomson	0668
Tokai	0684
Toshiba	0571,0640
Universum	0682
Wesder	0689
Wharfedale	0687
Wilson	3014
Xoro	3017
Yakumo	3018
Yamaha	0646
Yamakawa	0684,3016
Zenith	0570,0682
Others	0674

AUX Codes

BBK	3001,3002
Blaupunkt	0569(VHS)
Cabletime	0524,0525,0526(CTV)
Denon	0564(TUNE) ,0566(DECK)
Grundig	3019
Hitachi	3020,3021
LG	3022
Microsoft	0621(MCE)
Philips	0560(EQ),0561(PIP),0562(TAPE),0565(TUNE),0567(DCC)
ROTEL	0584(TAPE)
Samsung	3024
Sony	3023,0563(TAPE),0575(CDV),0618(TUNE)
Toshiba	3025